

				Name	Date	
			Drawn By			r@@I@HARNESS
Title CD 15 Door CAN Hornoon	Part Number CD15 Dags CAA	NULlawasas	Eng Approved			
SR-15 Rear CAN Harness SR15		15 Rear CAN Harness				This document contains confidential and proprietary information
Description		Revision	QA			that cannot be reproduced or divulged, in whole or in part, without written authorization.

Flag	Quantity	Not

Notes 1 of 1 Page 2 of 13



Id	Туре	Manufacturer	Part Number	Description	Quantity	Usage
3	Connector	TE Connectivity	T4112001081-000	Conn M12 Circular F 8 POS Screw RA Cable Mount 8	7	BMS, DAQ, MCU,
				Terminal 1 Port		RL_Brake_Rotor_Temp,
						RL_Tire_Temp,
						RR_Brake_Rotor_Temp,
						RR_Tire_temp
4	Connector	Omega Engineering	M12.8-T-SPLIT	Conn, Splitter, 8Pos, M12 Rcpt, Cable Rohs	7	T_Splitter1, T_Splitter2,
				Compliant: Yes  Omega M12.8-T-SPLIT		T_Splitter3, T_Splitter4,
						T_Splitter5, T_Splitter6,
						T_Splitter7
5	Connector	TE Connectivity	T4113002081-000	TE CONNECTIVITY T4113002081-000 Sensor Connector,	1	FW
				8 Pole, M12, Plug, Sensors & ActuatorsNew		
6	Wire	milspecwiring	M22759/33-24-9		≥ 82 in	W1, W2, W3, W4, W5, W6, W7,
						W8, W9, W10, W11, W173, W174,
						W175, W176, W177, W178, W179,
						W180, W181, W182, W183, W184,
						W185, W186, W187
	Cable					CBL1
8						W12
9	Wire		M22759/32-22-2	M22759 22 AWG Red Tin Plated Copper wire	≥ 70 in	W13, W14, W15, W16, W17, W18,
						W19, W20, W21, W22, W23, W24,
						W25, W26, W27, W28, W29, W30,
						W31, W32, W133, W134, W135,
						W136, W137, W138, W139, W140,
						W141, W142, W143, W144, W145,
						W146, W147, W148, W149, W150,
						W151, W152
10	Wire		M22759/32-22-5	M22759 22 AWG Green Tin Plated Copper wire	≥ 82 in	W33, W34, W35, W36, W37, W38,
						W39, W40, W41, W42, W43, W44,
						W45, W46, W47, W48, W49, W50,
						W51, W52
11	Wire		M22759/32-22-4	M22759 22 AWG Yellow Tin Plated Copper wire	≥ 70 in	W53, W54, W55, W56, W57, W58,
						W59, W60, W61, W62, W63, W64,
						W65, W66, W67, W68, W69, W70,
4.0	14.0		M22750/22 22 6	MANAZEO 22 MANG C. T' PL : LC		W71, W72
12	Wire		M22759/32-22-8	M22759 22 AWG Gray Tin Plated Copper wire	≥ 76 in	W73, W74, W75, W76, W77, W78,
						W79, W80, W81, W82, W83, W84,
						W85, W86, W87, W88, W89, W90,
	110		1400750 200 5	14007F0 00 MMCN" 1 - T1 - T1 - T1 - T1		W91, W92
13	Wire		M22759/32-22-7	M22759 22 AWG Violet Tin Plated Copper wire	≥ 82 in	W93, W94, W95, W96, W97, W98,
						W99, W100, W101, W102, W103,
						W104, W105, W106, W107, W108,

Page 3 of 13

Title:	
Part Number:	SR15 Rear CAN Harness
Description:	



Id	Туре	Manufacturer	Part Number	Description	Quantity	Usage
						W109, W110, W111, W112
14	Wire		M22759/32-22-6	M22759 22 AWG Blue Tin Plated Copper wire	≥ 76 in	W113, W114, W115, W116, W117,
						W118, W119, W120, W121, W122,
						W123, W124, W125, W126, W127,
						W128, W129, W130, W131, W132
15	Cable				0 in	CBL2
16	Wire		M22759/22-22-1	M22759 22 AWG Brown Silver Plated Copper Alloy	≥ 82 in	W153, W154, W155, W156, W157,
				wire		W158, W159, W160, W161, W162,
						W163, W164, W165, W166, W167,
						W168, W169, W170, W171, W172
17	Connector	TE Connectivity	T4112002051-000	Nickel M12 RoHS Compliant 2016 Circular Connector	1	MasterPanel
				24AWG -40C~85C 4A 60V		

Bill of Materials 2 of 2 Page 4 of 13





From	То	Conductor	Conductor PN	Twisted With	Gauge	Length	From Contact PN	Notes
FW.1	T_Splitter1.0_1	☐☐ W1.White	M22759/33-24-9		24 AWG	16 in		Sensor GND
FW.2	T_Splitter1.0_2	W153.Brown	M22759/22-22-1		22 AWG	16 in		CAN 0 H
FW.3	T_Splitter1.0_3	W33.Green	M22759/32-22-5		22 AWG	16 in		CAN 0 L
FW.4	T_Splitter1.0_4	W53.Yellow	M22759/32-22-4		22 AWG	16 in		CAN 1 H
FW.5	T_Splitter1.0_5	W73.Gray	M22759/32-22-8		22 AWG	16 in		CAN 1 L
FW.6	T_Splitter1.0_6	W93.Violet	M22759/32-22-7		22 AWG	16 in		CAN 2 H
FW.7	T_Splitter1.0_7	W113.Blue	M22759/32-22-6		22 AWG	16 in		CAN 2 L
FW.8	T_Splitter1.0_8	W133.Red	M22759/32-22-2		22 AWG	16 in		Sensor 5V
T_Splitter1.1_1	DAQ.1	W11.White	M22759/33-24-9		24 AWG	8 in		Sensor GND
T_Splitter1.1_2	DAQ.2	W154.Brown	M22759/22-22-1		22 AWG	8 in		CAN 0 H
T_Splitter1.1_3	DAQ.3	W34.Green	M22759/32-22-5		22 AWG	8 in		CAN 0 L
T_Splitter1.1_4	DAQ.4	W54.Yellow	M22759/32-22-4		22 AWG	8 in		CAN 1 H
T_Splitter1.1_5	DAQ.5	W74.Gray	M22759/32-22-8		22 AWG	8 in		CAN 1 L
T_Splitter1.1_6	DAQ.6	W94.Violet	M22759/32-22-7		22 AWG	8 in		CAN 2 H
T_Splitter1.1_7	DAQ.7	W114.Blue	M22759/32-22-6		22 AWG	8 in		CAN 2 L
T_Splitter1.1_8	DAQ.8	W15.Red	M22759/32-22-2		22 AWG	8 in		Sensor 5V
T_Splitter1.2_1	T_Splitter2.0_1	W3.White	M22759/33-24-9		24 AWG	4 in		Sensor GND
T_Splitter1.2_2	T_Splitter2.0_2	W155.Brown	M22759/22-22-1		22 AWG	4 in		CAN 0 H
T_Splitter1.2_3	T_Splitter2.0_3	W35.Green	M22759/32-22-5		22 AWG	4 in		CAN 0 L
T_Splitter1.2_4	T_Splitter2.0_4	W56.Yellow	M22759/32-22-4		22 AWG	4 in		CAN 1 H
T_Splitter1.2_5	T_Splitter2.0_5	W76.Gray	M22759/32-22-8		22 AWG	4 in		CAN 1 L
T_Splitter1.2_6	T_Splitter2.0_6	W96.Violet	M22759/32-22-7		22 AWG	4 in		CAN 2 H
T_Splitter1.2_7	T_Splitter2.0_7	<b>W</b> 116.Blue	M22759/32-22-6		22 AWG	4 in		CAN 2 L
T_Splitter1.2_8	T_Splitter2.0_8	<b>W</b> 134.Red	M22759/32-22-2		22 AWG	4 in		Sensor 5V
T_Splitter2.1_1	T_Splitter3.0_1	W2.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter2.1_2	T_Splitter3.0_2	W156.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter2.1_3	T_Splitter3.0_3	W36.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter2.1_4	T_Splitter3.0_4	W61.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter2.1_5	T_Splitter3.0_5	W75.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter2.1_6	T_Splitter3.0_6	W95.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter2.1_7	T_Splitter3.0_7	W115.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter2.1_8	T_Splitter3.0_8	W135.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter2.2_1	MasterPanel.5	☐☐ W5.White	M22759/33-24-9		24 AWG	12 in		Sensor GND
T_Splitter2.2_2	MasterPanel.2	W158.Brown	M22759/22-22-1		22 AWG	12 in		CAN 0 H
T_Splitter2.2_3	MasterPanel.1	W37.Green	M22759/32-22-5		22 AWG	12 in		CAN 0 L
T_Splitter2.2_6	MasterPanel.3	W97.Violet	M22759/32-22-7		22 AWG	12 in		CAN 2 H
T_Splitter2.2_7	MasterPanel.4	W117.Blue	M22759/32-22-6		22 AWG	12 in		CAN 2 L
T_Splitter3.1_1	MCU.1	W4.White	M22759/33-24-9		24 AWG			Description
T_Splitter3.1_2	MCU.2	W157.Brown	M22759/22-22-1		22 AWG			CAN 0 H
T_Splitter3.1_3	MCU.3	W38.Green	M22759/32-22-5		22 AWG			CAN 0 L
T_Splitter3.1_4	MCU.4	W58.Yellow	M22759/32-22-4		22 AWG			CAN 1 H

Wiring Table 1 of 3 Page 5 of 13



From	То	Conductor	Conductor PN	Twisted With	Gauge	Length	From Contact PN	Notes
T_Splitter3.1_5	MCU.5	W77.Gray	M22759/32-22-8		22 AWG			CAN 1 L
T_Splitter3.1_6	MCU.6	W98.Violet	M22759/32-22-7		22 AWG			CAN 2 H
T_Splitter3.1_7	MCU.7	W118.Blue	M22759/32-22-6		22 AWG			CAN 2 L
T_Splitter3.1_8	MCU.8	W136.Red	M22759/32-22-2		22 AWG			Sensor 5V
T_Splitter3.2_1	T_Splitter4.0_1	W10.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter3.2_2	T_Splitter4.0_2	W159.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter3.2_3	T_Splitter4.0_3	W39.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter3.2_4	T_Splitter4.0_4	W55.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter3.2_5	T_Splitter4.0_5	W78.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter3.2_6	T_Splitter4.0_6	W92.Gray	M22759/32-22-8		22 AWG	6 in		CAN 2 H
T_Splitter3.2_7	T_Splitter4.0_7	W119.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter3.2_8	T_Splitter4.0_8	W138.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter4.1_1	BMS.1	☐☐ W6.White	M22759/33-24-9		24 AWG			Sensor GND
T_Splitter4.1_2	BMS.2	W160.Brown	M22759/22-22-1		22 AWG			CAN 0 H
T_Splitter4.1_3	BMS.3	W40.Green	M22759/32-22-5		22 AWG			CAN 0 L
T_Splitter4.1_4	BMS.4	W57.Yellow	M22759/32-22-4		22 AWG			CAN 1 H
T_Splitter4.1_5	BMS.5	W79.Gray	M22759/32-22-8		22 AWG			CAN 1 L
T_Splitter4.1_6	BMS.6	W99.Violet	M22759/32-22-7		22 AWG			CAN 2 H
T_Splitter4.1_7	BMS.7	W120.Blue	M22759/32-22-6		22 AWG			CAN 2 L
T_Splitter4.1_8	BMS.8	W137.Red	M22759/32-22-2		22 AWG			Sensor 5V
T_Splitter4.2_1	T_Splitter5.0_1	W7.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter4.2_2	T_Splitter5.0_2	W161.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter4.2_3	T_Splitter5.0_3	W41.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter4.2_4	T_Splitter5.0_4	W59.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter4.2_5	T_Splitter5.0_5	W80.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter4.2_6	T_Splitter5.0_6	W100.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter4.2_7	T_Splitter5.0_7	<b>W</b> 121.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter4.2_8	T_Splitter5.0_8	W139.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter5.1_1	T_Splitter6.0_1	W9.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter5.1_2	T_Splitter6.0_2	W162.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter5.1_3	T_Splitter6.0_3	W42.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter5.1_4	T_Splitter6.0_4	W60.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter5.1_5	T_Splitter6.0_5	W81.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter5.1_6	T_Splitter6.0_6	W101.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter5.1_7	T_Splitter6.0_7	W122.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter5.1_8	T_Splitter6.0_8	<b>W</b> 140.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter5.2_1	T_Splitter7.0_1	W174.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter5.2_2	T_Splitter7.0_2	W171.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter5.2_3	T_Splitter7.0_3	W49.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter5.2_4	T_Splitter7.0_4	W65.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter5.2_5	T_Splitter7.0_5	W85.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L

Wiring Table 2 of 3 Page 6 of 13

Title:	
Part Number:	SR15 Rear CAN Harness
Description:	



From	То	Conductor	Conductor PN	Twisted With	Gauge	Length	From Contact PN	Notes
T_Splitter5.2_6	T_Splitter7.0_6	W104.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter5.2_7	T_Splitter7.0_7	W125.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter5.2_8	T_Splitter7.0_8	<b>W</b> 143.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter6.1_1	RR_Tire_temp.1	W8.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter6.1_2	RR_Tire_temp.2	W163.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter6.1_3	RR_Tire_temp.3	W43.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter6.1_4	RR_Tire_temp.4	W62.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter6.1_5	RR_Tire_temp.5	W82.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter6.1_6	RR_Tire_temp.6	W103.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter6.1_7	RR_Tire_temp.7	W123.Blue	M22759/32-22-6		22 AWG	6 in		CAN 2 L
T_Splitter6.1_8	RR_Tire_temp.8	<b>W</b> 141.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter6.2_1	RR_Brake_Rotor_Temp.1	W173.White	M22759/33-24-9		24 AWG			Sensor GND
T_Splitter6.2_2	RR_Brake_Rotor_Temp.2	W172.Brown	M22759/22-22-1		22 AWG			CAN 0 H
T_Splitter6.2_3	RR_Brake_Rotor_Temp.3	W44.Green	M22759/32-22-5		22 AWG			CAN 0 L
T_Splitter6.2_4	RR_Brake_Rotor_Temp.4	W63.Yellow	M22759/32-22-4		22 AWG			CAN 1 H
T_Splitter6.2_5	RR_Brake_Rotor_Temp.5	W83.Gray	M22759/32-22-8		22 AWG			CAN 1 L
T_Splitter6.2_6	RR_Brake_Rotor_Temp.6	W102.Violet	M22759/32-22-7		22 AWG			CAN 2 H
T_Splitter6.2_7	RR_Brake_Rotor_Temp.7	W124.Blue	M22759/32-22-6		22 AWG			CAN 2 L
T_Splitter6.2_8	RR_Brake_Rotor_Temp.8	<b>W</b> 142.Red	M22759/32-22-2		22 AWG			Sensor 5V
T_Splitter7.1_1	RL_Tire_Temp.1	W175.White	M22759/33-24-9		24 AWG	6 in		Sensor GND
T_Splitter7.1_2	RL_Tire_Temp.2	W170.Brown	M22759/22-22-1		22 AWG	6 in		CAN 0 H
T_Splitter7.1_3	RL_Tire_Temp.3	W45.Green	M22759/32-22-5		22 AWG	6 in		CAN 0 L
T_Splitter7.1_4	RL_Tire_Temp.4	W64.Yellow	M22759/32-22-4		22 AWG	6 in		CAN 1 H
T_Splitter7.1_5	RL_Tire_Temp.5	W84.Gray	M22759/32-22-8		22 AWG	6 in		CAN 1 L
T_Splitter7.1_6	RL_Tire_Temp.6	W105.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 H
T_Splitter7.1_7	RL_Tire_Temp.7	W112.Violet	M22759/32-22-7		22 AWG	6 in		CAN 2 L
T_Splitter7.1_8	RL_Tire_Temp.8	<b>W</b> 144.Red	M22759/32-22-2		22 AWG	6 in		Sensor 5V
T_Splitter7.2_1	RL_Brake_Rotor_Temp.1	W176.White	M22759/33-24-9		24 AWG			Sensor GND
T_Splitter7.2_2	RL_Brake_Rotor_Temp.2	W169.Brown	M22759/22-22-1		22 AWG			CAN 0 H
T_Splitter7.2_3	RL_Brake_Rotor_Temp.3	W46.Green	M22759/32-22-5		22 AWG			CAN 0 L
T_Splitter7.2_4	RL_Brake_Rotor_Temp.4	W66.Yellow	M22759/32-22-4		22 AWG			CAN 1 H
T_Splitter7.2_5	RL_Brake_Rotor_Temp.5	W72.Yellow	M22759/32-22-4		22 AWG			CAN 1 L
T_Splitter7.2_6	RL_Brake_Rotor_Temp.6	W106.Violet	M22759/32-22-7		22 AWG			CAN 2 H
T_Splitter7.2_7	RL_Brake_Rotor_Temp.7	W126.Blue	M22759/32-22-6		22 AWG			CAN 2 L
T_Splitter7.2_8	RL_Brake_Rotor_Temp.8	W145.Red	M22759/32-22-2		22 AWG			Sensor 5V

Wiring Table 3 of 3 Page 7 of 13





#	Туре	Reference Designator	Manufacturer	Part Number	Color	Gauge	From Strip	To Strip	Length	Twisted With
1	Cable	CBL1			■ Blue				0 in	
2	Cable	CBL2			■ Blue				0 in	
3	Wire	W1	milspecwiring	M22759/33-24-9	White	24 AWG			16 in	
4	Wire	W2	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			6 in	
5	Wire	W3	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			4 in	
6	Wire	W4	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG				
7	Wire	W5	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			12 in	
8	Wire	W6	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG				
9	Wire	W7	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			6 in	
10	Wire	W8	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			6 in	
11	Wire	W9	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			6 in	
12	Wire	W10	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			6 in	
13	Wire	W11	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			8 in	
14	Wire	W12			Unspecified				0 in	
15	Wire	W13		M22759/32-22-2	Red	22 AWG			0 in	
16	Wire	W14		M22759/32-22-2	Red	22 AWG			0 in	
17	Wire	W15		M22759/32-22-2	Red	22 AWG			8 in	
18	Wire	W16		M22759/32-22-2	Red	22 AWG			0 in	
19	Wire	W17		M22759/32-22-2	Red	22 AWG			0 in	
20	Wire	W18		M22759/32-22-2	Red	22 AWG			0 in	
21	Wire	W19		M22759/32-22-2	Red	22 AWG			0 in	
22	Wire	W20		M22759/32-22-2	Red	22 AWG			0 in	
23	Wire	W21		M22759/32-22-2	Red	22 AWG			0 in	
24	Wire	W22		M22759/32-22-2	Red	22 AWG			0 in	
25	Wire	W23		M22759/32-22-2	Red	22 AWG			0 in	
26	Wire	W24		M22759/32-22-2	Red	22 AWG			0 in	
27	Wire	W25		M22759/32-22-2	Red	22 AWG			0 in	
28	Wire	W26		M22759/32-22-2	Red	22 AWG			0 in	
29	Wire	W27		M22759/32-22-2	Red	22 AWG			0 in	
30	Wire	W28		M22759/32-22-2	Red	22 AWG			0 in	
31	Wire	W29		M22759/32-22-2	Red	22 AWG			0 in	
32	Wire	W30		M22759/32-22-2	Red	22 AWG			0 in	
33	Wire	W31		M22759/32-22-2	Red	22 AWG			0 in	
34	Wire	W32		M22759/32-22-2	Red	22 AWG			0 in	
35	Wire	W33		M22759/32-22-5	Green	22 AWG			16 in	
36	Wire	W34		M22759/32-22-5	Green	22 AWG			8 in	
37	Wire	W35		M22759/32-22-5	Green	22 AWG			4 in	
38	Wire	W36		M22759/32-22-5	Green	22 AWG			6 in	
39	Wire	W37		M22759/32-22-5	Green	22 AWG			12 in	
40		W38		M22759/32-22-5	Green	22 AWG				
41	Wire	W39		M22759/32-22-5	Green	22 AWG			6 in	

Cutlist 1 of 5 Page 8 of 13



#	Type	Reference Designator	Manufacturer	Part Number	Color	Gauge	From Strip	To Strip	Length	Twisted With
42	Wire	W40		M22759/32-22-5	Green	22 AWG				
43	Wire	W41		M22759/32-22-5	Green	22 AWG			6 in	
44	Wire	W42		M22759/32-22-5	Green	22 AWG			6 in	
45	Wire	W43		M22759/32-22-5	Green	22 AWG			6 in	
46	Wire	W44		M22759/32-22-5	Green	22 AWG				
47	Wire	W45		M22759/32-22-5	Green	22 AWG			6 in	
48	Wire	W46		M22759/32-22-5	Green	22 AWG				
49	Wire	W47		M22759/32-22-5	Green	22 AWG			0 in	
50	Wire	W48		M22759/32-22-5	Green	22 AWG			0 in	
51	Wire	W49		M22759/32-22-5	Green	22 AWG			6 in	
52	Wire	W50		M22759/32-22-5	Green	22 AWG			0 in	
53	Wire	W51		M22759/32-22-5	Green	22 AWG			0 in	
54	Wire	W52		M22759/32-22-5	Green	22 AWG			0 in	
55	Wire	W53		M22759/32-22-4	Yellow	22 AWG			16 in	
56	Wire	W54		M22759/32-22-4	Yellow	22 AWG			8 in	
57	Wire	W55		M22759/32-22-4	Yellow	22 AWG			6 in	
58	Wire	W56		M22759/32-22-4	Yellow	22 AWG			4 in	
59	Wire	W57		M22759/32-22-4	Yellow	22 AWG				
60	Wire	W58		M22759/32-22-4	Yellow	22 AWG				
61	Wire	W59		M22759/32-22-4	Yellow	22 AWG			6 in	
62	Wire	W60		M22759/32-22-4	Yellow	22 AWG			6 in	
63	Wire	W61		M22759/32-22-4	Yellow	22 AWG			6 in	
64	Wire	W62		M22759/32-22-4	Yellow	22 AWG			6 in	
65	Wire	W63		M22759/32-22-4	Yellow	22 AWG				
66	Wire	W64		M22759/32-22-4	Yellow	22 AWG			6 in	
67	Wire	W65		M22759/32-22-4	Yellow	22 AWG			6 in	
68	Wire	W66		M22759/32-22-4	Yellow	22 AWG				
69	Wire	W67		M22759/32-22-4	Yellow	22 AWG			0 in	
70	Wire	W68		M22759/32-22-4	Yellow	22 AWG			0 in	
71	Wire	W69		M22759/32-22-4	Yellow	22 AWG			0 in	
72	Wire	W70		M22759/32-22-4	Yellow	22 AWG			0 in	
73	Wire	W71		M22759/32-22-4	Yellow	22 AWG			0 in	
74	Wire	W72		M22759/32-22-4	Yellow	22 AWG				
75	Wire	W73		M22759/32-22-8	Gray	22 AWG			16 in	
76	Wire	W74		M22759/32-22-8	Gray	22 AWG			8 in	
77	Wire	W75		M22759/32-22-8	Gray	22 AWG			6 in	
78	Wire	W76		M22759/32-22-8	Gray	22 AWG			4 in	
79	Wire	W77		M22759/32-22-8	Gray	22 AWG				
80	Wire	W78		M22759/32-22-8	Gray	22 AWG			6 in	
81	Wire	W79		M22759/32-22-8	Gray	22 AWG				
82	Wire	W80		M22759/32-22-8	Gray	22 AWG			6 in	

Cutlist 2 of 5 Page 9 of 13



#	Туре	Reference Designator	Manufacturer	Part Number	Color	Gauge	From Strip	To Strip	Length	Twisted With
83	Wire	W81		M22759/32-22-8	Gray	22 AWG			6 in	
84	Wire	W82		M22759/32-22-8	Gray	22 AWG			6 in	
85	Wire	W83		M22759/32-22-8	Gray	22 AWG				
86	Wire	W84		M22759/32-22-8	Gray	22 AWG			6 in	
87	Wire	W85		M22759/32-22-8	Gray	22 AWG			6 in	
88	Wire	W86		M22759/32-22-8	Gray	22 AWG			0 in	
89	Wire	W87		M22759/32-22-8	Gray	22 AWG			0 in	
90	Wire	W88		M22759/32-22-8	Gray	22 AWG			0 in	
91	Wire	W89		M22759/32-22-8	Gray	22 AWG			0 in	
92	Wire	W90		M22759/32-22-8	Gray	22 AWG			0 in	
93	Wire	W91		M22759/32-22-8	Gray	22 AWG			0 in	
94	Wire	W92		M22759/32-22-8	Gray	22 AWG			6 in	
95	Wire	W93		M22759/32-22-7	Violet	22 AWG			16 in	
96	Wire	W94		M22759/32-22-7	Violet	22 AWG			8 in	
97	Wire	W95		M22759/32-22-7	Violet	22 AWG			6 in	
98	Wire	W96		M22759/32-22-7	Violet	22 AWG			4 in	
99	Wire	W97		M22759/32-22-7	Violet	22 AWG			12 in	
100	Wire	W98		M22759/32-22-7	Violet	22 AWG				
101	Wire	W99		M22759/32-22-7	Violet	22 AWG				
102	Wire	W100		M22759/32-22-7	Violet	22 AWG			6 in	
103	Wire	W101		M22759/32-22-7	Violet	22 AWG			6 in	
104	Wire	W102		M22759/32-22-7	Violet	22 AWG				
105	Wire	W103		M22759/32-22-7	Violet	22 AWG			6 in	
106	Wire	W104		M22759/32-22-7	Violet	22 AWG			6 in	
107	Wire	W105		M22759/32-22-7	Violet	22 AWG			6 in	
108	Wire	W106		M22759/32-22-7	Violet	22 AWG				
109	Wire	W107		M22759/32-22-7	Violet	22 AWG			0 in	
110	Wire	W108		M22759/32-22-7	Violet	22 AWG			0 in	
111	Wire	W109		M22759/32-22-7	Violet	22 AWG			0 in	
112	Wire	W110		M22759/32-22-7	Violet	22 AWG			0 in	
113	Wire	W111		M22759/32-22-7	Violet	22 AWG			0 in	
114	Wire	W112		M22759/32-22-7	Violet	22 AWG			6 in	
115	Wire	W113		M22759/32-22-6	Blue	22 AWG			16 in	
116	Wire	W114		M22759/32-22-6	Blue	22 AWG			8 in	
117	Wire	W115		M22759/32-22-6	Blue	22 AWG			6 in	
118	Wire	W116		M22759/32-22-6	Blue	22 AWG			4 in	
119	Wire	W117		M22759/32-22-6	Blue	22 AWG			12 in	
120	Wire	W118		M22759/32-22-6	Blue	22 AWG				
121	Wire	W119		M22759/32-22-6	Blue	22 AWG			6 in	
122	Wire	W120		M22759/32-22-6	Blue	22 AWG				
123	Wire	W121		M22759/32-22-6	Blue	22 AWG			6 in	

Cutlist 3 of 5 Page 10 of 13



#	Туре	Reference Designator	Manufacturer	Part Number	Color	Gauge	From Strip	To Strip	Length	Twisted With
124	Wire	W122		M22759/32-22-6	Blue	22 AWG			6 in	
125	Wire	W123		M22759/32-22-6	Blue	22 AWG			6 in	
126	Wire	W124		M22759/32-22-6	Blue	22 AWG				
127	Wire	W125		M22759/32-22-6	Blue	22 AWG			6 in	
128	Wire	W126		M22759/32-22-6	Blue	22 AWG				
129	Wire	W127		M22759/32-22-6	Blue	22 AWG			0 in	
130	Wire	W128		M22759/32-22-6	Blue	22 AWG			0 in	
131	Wire	W129		M22759/32-22-6	Blue	22 AWG			0 in	
132	Wire	W130		M22759/32-22-6	Blue	22 AWG			0 in	
133	Wire	W131		M22759/32-22-6	Blue	22 AWG			0 in	
134	Wire	W132		M22759/32-22-6	Blue	22 AWG			0 in	
135	Wire	W133		M22759/32-22-2	Red	22 AWG			16 in	
136	Wire	W134		M22759/32-22-2	Red	22 AWG			4 in	
137	Wire	W135		M22759/32-22-2	Red	22 AWG			6 in	
138	Wire	W136		M22759/32-22-2	Red	22 AWG				
139	Wire	W137		M22759/32-22-2	Red	22 AWG				
140	Wire	W138		M22759/32-22-2	Red	22 AWG			6 in	
141	Wire	W139		M22759/32-22-2	Red	22 AWG			6 in	
142	Wire	W140		M22759/32-22-2	Red	22 AWG			6 in	
143	Wire	W141		M22759/32-22-2	Red	22 AWG			6 in	
144	Wire	W142		M22759/32-22-2	Red	22 AWG				
145	Wire	W143		M22759/32-22-2	Red	22 AWG			6 in	
146	Wire	W144		M22759/32-22-2	Red	22 AWG			6 in	
147	Wire	W145		M22759/32-22-2	Red	22 AWG				
148	Wire	W146		M22759/32-22-2	Red	22 AWG			0 in	
149	Wire	W147		M22759/32-22-2	Red	22 AWG			0 in	
	Wire	W148		M22759/32-22-2	Red	22 AWG			0 in	
151	Wire	W149		M22759/32-22-2	Red	22 AWG			0 in	
152	Wire	W150		M22759/32-22-2	Red	22 AWG			0 in	
	Wire	W151		M22759/32-22-2	Red	22 AWG			0 in	
154	Wire	W152		M22759/32-22-2	Red	22 AWG			0 in	
	Wire	W153		M22759/22-22-1	Brown	22 AWG			16 in	
	Wire	W154		M22759/22-22-1	Brown	22 AWG			8 in	
157		W155		M22759/22-22-1	Brown	22 AWG			4 in	
	Wire	W156		M22759/22-22-1	Brown	22 AWG			6 in	
	Wire	W157		M22759/22-22-1	Brown	22 AWG				
	Wire	W158		M22759/22-22-1	Brown	22 AWG			12 in	
161		W159		M22759/22-22-1	Brown	22 AWG			6 in	
	Wire	W160		M22759/22-22-1	Brown	22 AWG				
163		W161		M22759/22-22-1	Brown	22 AWG			6 in	
	Wire	W162		M22759/22-22-1	Brown	22 AWG			6 in	

Cutlist 4 of 5 Page 11 of 13

Title:	
Part Number:	SR15 Rear CAN Harness
Description:	



#	Туре	Reference Designator	Manufacturer	Part Number	Color	Gauge	From Strip	To Strip	Length	Twisted With
165	Wire	W163		M22759/22-22-1	Brown	22 AWG			6 in	
166	Wire	W164		M22759/22-22-1	Brown	22 AWG			0 in	
167	Wire	W165		M22759/22-22-1	Brown	22 AWG			0 in	
168	Wire	W166		M22759/22-22-1	Brown	22 AWG			0 in	
169	Wire	W167		M22759/22-22-1	Brown	22 AWG			0 in	
170	Wire	W168		M22759/22-22-1	Brown	22 AWG			0 in	
171	Wire	W169		M22759/22-22-1	Brown	22 AWG				
172	Wire	W170		M22759/22-22-1	Brown	22 AWG			6 in	
173	Wire	W171		M22759/22-22-1	Brown	22 AWG			6 in	
174	Wire	W172		M22759/22-22-1	Brown	22 AWG				
175	Wire	W173	milspecwiring	M22759/33-24-9	White	24 AWG				
176	Wire	W174	milspecwiring	M22759/33-24-9	White	24 AWG			6 in	
177	Wire	W175	milspecwiring	M22759/33-24-9	White	24 AWG			6 in	
178	Wire	W176	milspecwiring	M22759/33-24-9	White	24 AWG				
179	Wire	W177	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
180	Wire	W178	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
181	Wire	W179	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
182	Wire	W180	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
183	Wire	W181	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
184	Wire	W182	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
185	Wire	W183	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	
186	Wire	W184	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			0 in	
187	Wire	W185	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			0 in	
188	Wire	W186	milspecwiring	M22759/33-24-9	☐☐ White	24 AWG			0 in	
189	Wire	W187	milspecwiring	M22759/33-24-9	White	24 AWG			0 in	

Cutlist 5 of 5 Page 12 of 13





#	Manufacturer	Part Number	Description	Label Text

Labels 1 of 1 Page 13 of 13